



8

Interchangeable parts • Éléments interchangeables • Partes intercambiables • Austauschbare Teile
Componenti intercambiabili • 組み換え可能な部品 • 可互換零件 • 선택 가능 부품



8

a

x2



C75



C76



C77



C78



C79



C85



C88



C86



C89



C87



8

b

x2



C80



C81



C82



C83



C84



C90



C91



C92

! 9 - 10



≤2



≤2

- Choose the variant you want to build
- Choisissez la variante à assembler
- Elige qué versión quieres montar
- Wähle die Variante, die du bauen möchtest
- Scegli la variante che vuoi assemblare
- 組み立てバリエーションの選択
- 选择你喜欢的拼装方式
- 조립 옵션을 선택하세요



9

a ; b-c



• Champion • Campeón • Campione
• 豪傑 • 勇士 • 용사



9

a ; d-e



• Gluttons • Gloutons • Glotones
• Hungrige Ogors • Ingordi • グラットン
• 暴食者 • 식탐꾼



10

a ; b-c



• Champion • Campeón • Campione
• 豪傑 • 勇士 • 용사





10

a ; d-e





• Gluttons • Gloutons • Glotones
• Hungrige Ogors • Ingordi • グラットン
• 暴食者 • 식탐꾼


! 9 a x2





! 9 b ≤1



! 9 c



9 d ≤2



9 e



C11



C16



C15



C93



C94




C95




! 10 a x2

C18




C23

C19





C22




C20

10 b ≤1



10 c




C26





C100



C99

C25



10 d ≤2





! 11-12



- Choose the variant you want to build
- Choisissez la variante à assembler
- Elige qué versión quieres montar
- Wähle die Variante, die du bauen möchtest
- Scegli la variante che vuoi assemblare
- 組み立てバリエーションの選択
- 选择你喜欢的拼装方式
- 조립 옵션을 선택하세요

11 a ; b-c



- Musician • Musicien • Músico • Musiker
- Musico • 樂士 • 乐师 • 악사

12 a ; b-c



- Musician • Musicien • Músico • Musiker
- Musico • 樂士 • 乐师 • 악사

11 a ; d-e





- Gluttons • Gloutons • Glotones
- Hungrige Ogors • Ingordi • グラットン
- 暴食者 • 식탐꾼

12 a ; d-e





- Gluttons • Gloutons • Glotones
- Hungrige Ogors • Ingordi • グラットン
- 暴食者 • 식탐꾼


! 11 a x2





⚙️ 11 b ≤1





⚙️ 11 c





11 d ≤2







11 e





12 a x2









11 d ≤2





11 e





! 12 a x2




! 11 a x2





11 b ≤1





11 c





11 d ≤2





11 e





12 a x2





12 b ≤1





12 c





12 d ≤2



12 e



13 a x2



- Choose the variant you want to build
- Choisissez la variante à assembler
- Elige qué versión quieres montar
- Wähle die Variante, die du bauen möchtest
- Scegli la variante che vuoi assemblare
- 組み立てバリエーションの選択
- 选择你喜欢的拼装方式
- 조립 옵션을 선택하세요



13 b - c






13 d - e





13 b ≤2



13 c



13 d ≤2



13 e



C73




C72



C98




C101



8 b

8 a

13 d



Ø 40mm



C68



C74

✓ 8 - 13

